
KitchenAid®

COOKTOP PARTS

For Models: KECC506RSS04
(STAINLESS)

30" ELECTRIC
CERAN
COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS
For Models: KECC506RSS04
(STAINLESS)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
		Installation Instructions
	8286066	English/French
	8304571	Canadian
	8286073	Wiring Diagram
	W10162162	Use & Care Guide
		Safer Cooking Tips
	9762761	English
	W10065852	French
2	8286946	Cooktop, Glass
3	246119	Screw
4	8285935	Bracket, Switch Mounting
5	9759094	Spring Locator (8)
6		Switch, Infinite
	3191049	LR − RF
	4456027	RR
	8286070	LF
7	3183956	Seal, Switch Shaft
8	8286096BL	Knob, Control (4)
9	8285862	Box, Burner
10	4455917	Bracket, Mounting
11	3400093	Screw
12	3196537	Screw
13	8285469	Seal, Switch
14	311865	Screw
15	9763517	Rail, Element (2)
16	8286344	Rail, Element (1)
17	8286055	Lamp, Hot Surface Indicator
18	W10142240	Frame, Cooktop
19		Element, Surface
	8523698	1200W LR
	8523697	1500W RF
	8285937	2000/1000W RR
	8285846	2500/1800/900W LF
20	4455468	Shield−Heat, Control
21		Seal, Heat Shield
	3191839	8.74"
	8286426	6.41"
22	8286607	Grommet, Flexible

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KECC506RSS04
(STAINLESS)

Illus. No.	Part No.	DESCRIPTION
Miscellaneous		
	8286642	Tape, Foam
SPLICING WIRES−−25FT. LENGTH		
	4456028	Wire, Jumper
	242828	Wire, Black 12 Ga. 150° C
	242820	Wire, Black 14 Ga. 150° C
	242822	Wire, Blue 14 Ga. 150° C
	242830	Wire, Brown 14 Ga. 200° C
	242823	Wire, Green 14 Ga. 150° C
	242824	Wire, Orange 14 Ga. 150° C
	242825	Wire, Red 14 Ga. 150° C
	242831	Wire, Red 14 Ga. 200° C
	242827	Wire, Yellow 14 Ga. 150° C
WIRING HARNESS PARTS		
	8286417	Wiring Harness
	3400015	Screw
	8286421	Conduit, Harness

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST